

產品包裝內容

編號	部件名称	数量
1	EVPAD	1
2	遙控器	1
3	產品說明書	1
4	高清視頻線	選配
5	適配器	1

註：1.此產品高清線為選配，實驗室抽驗時請進口商提供高清線。

2.本手冊涉及產品圖片及信息僅供參考，請以實物為準，如有任何變更，恕不另行通知。

3.建議用戶選購長度不超過1.2米、128編織網四層屏蔽雙磁環的高清線。

產品售後保固

保修期

1.凡購買本公司產品均可享受自購買起為期壹年的保修服務，保修期內持有效購機憑證可免費享受售後服務，有特殊約定的除外！


下列情況不屬於免費保修範圍，EVPAD可提供有償服務。

- 1.已經超過有效的保修期限；
- 2.未按使用說明書要求安裝，使用，維護保管而導致的故障或損壞；
- 3.非EVPAD授權的維修人員進行維修而導致的故障或損壞；
- 4.因意外因素或人為行為導致的產品損壞，如：摔壞、進水、輸入不適電壓、腐蝕等；
- 5.未經EVPAD允許，擅自改動產品固有的設置文件或未經認證的產品固件；
- 6.擅自塗改撕毀本售後服務卡、產品序列表；
- 7.客戶發回返修途中由於運輸、裝卸等所導致的損壞；
- 8.因火災、水災、雷電等不可抗力而造成的故障或損壞；
- 9.其他非產品本身設計、技術、制造質量等問題而導致的故障或損壞。

特別提醒

- 1.使用之前，請務必仔細讀產品說明書；
- 2.經銷商向您做出的非我可保證的承諾，我司不為此承擔責任；
- 3.在產品送修前，請聯系我司技術服務，尋求技術支持，以確認產品故障。

連接示意圖



“以太網”連接（插上網線即可接入互聯網）

1. 請確保連接機頂盒的網絡是從路由器引出的，並且路由器的DHCP功能打開。
2. 將網絡插入機頂盒的有線網絡接口，並確保網絡和機頂盒及路由器接觸良好。
3. 進入設置> 網絡和互聯網> 以太網> 確認以太網已連接。



無線連接/WIFI連接


設置> 網絡和互聯網> WIFI> 選中所需的無線連接> 輸入密碼



重要提示

您購買的機器支持2.4/5.8Ghz雙頻WIFI，如您的家庭網絡支持雙頻路由器，我們強烈推薦選擇5.8Ghz，因為高頻網絡連接至互聯網更快、更穩定！

語音遙控器使用說明/Voice remote control instructions



學習功能操作指南/Instruction of the Learning Function

- 1: 長按遙控器電視機按鍵區的“**OK**”按鍵約5秒鐘，直到遙控器紅色指示燈變為長亮狀態，此時進入學習狀態。
1. Press the programmable POWER key of the TV Box Remote Control for 5 seconds. The LED light will turn on, indicating that the programmable keys are in the programmable state.
- 2: 按下要學習的按鍵，紅色指示燈閃爍，此時處於學習接收狀態。
2. Press one of the programmable keys of the TV Box Remote Control, its LED light will flash.
- 3: 手持被學習的遙控器，對準機頂盒遙控器，距離大約3-5mm，按下被學習的按鍵。
3. Direct the head of the TV Remote Control at the head of the TV Box Remote Control. (Please keep 3-5cm distance between the two Remote Controls.)
- 4: 學習成功後紅色指示燈快速閃爍三下後繼續保持長亮，可以再次選擇其它學習按鍵進行學習。
4. Press down the original key of the TV Remote Control, the LED light of the TV Box Remote Control will flash 3 times quickly and then stay lit up, indicating that the programmable key has been programmed. To program other keys, please repeat step 2-3-4.
- 5: 如學習失敗則紅燈閃爍5次，返回學習狀態，重複步驟2-4。
5. The LED light will flash 5 times if the programmable key fail to be programmed. If so, please repeat step 2-3-4.
- 6: 學習完畢後，按電視機按鍵區以外的任意其它按鍵退出學習狀態；紅色指示燈熄滅。
6. Press any non-programmable key of the TV Box Remote Control to exit the programmable state.

*** 按鍵後，指示燈持續閃爍時間超過10秒，表示電池電量不足，請更換電池。**

When press the key, the LED flashes continuously for more than 10 seconds, indicating the battery is low. Please replace the battery.

免責聲明

使用說明及條款：

請在使用服務之前仔細閱讀本聲明，用戶有權選擇不使用此服務，壹旦使用，即被視為已經接收此免責聲明、版權協議及隱私原則等以下服務條款：

1. 免責聲明

a. 本產品作為壹款網絡多媒體播放機的同時，具有接入互聯網的功能，用戶自行下載安裝的應用程式均來自互聯網，本產品不對任何應用所包含的內容的正確性、合法性負責。請廣大用戶遵守所在地的相關法律法規，不要安裝使用有關色情、暴力、版權爭議等違規內容的應用程式。

b. 本產品作為開放系統平臺，可以運行大量第三方技術團隊開發的應用程式，因此難免存在部分應用程式與本產品不相容的情況。另外，所有資源來源於網絡，僅供個人學習於研究，版權歸原作者。所有下載的資源請在下載後24小時內刪除，否則由此產生的壹切後果由使用者承擔。

c. 本產品應用都來自互聯網以及互聯網應用開發者，本產品對應用內容不進行修改、編輯或整理。由應用開發及提交者承擔所有責任。因此給任何供應商造成的損失，本產品不負責任何法律責任。

d. 任何單位或個人認為通過被產品提供的軟體可能涉嫌侵犯其合法權益，應及時向被產品發出書面回饋，並提供身份證明、權屬證明及詳細侵權證明，將會盡快移除被侵權軟體。

2. 反通知

本產品根據前述通知移除相關內容的，被移除內容的內容提供者可以依法向本產品發出相關於被移除內容不侵犯著作權或其他合法權益的反通知。反通知發出後，本產品可以恢復被移除的內容，且依法對該行為不承擔法律責任。

請註意：如果您反通知的陳述失實，您將承擔對此造成的全部法律責任（包括但不限於賠償各種費用及律師費）。如果您不確定本產品本產品可獲取的資料是否侵犯了您的權利，我們建議您首先諮詢專業人士。

為了便於我們處理您的反通知，請使用以下格式（包括各條款的序號）：

- A.請指明被本產品移除的諮詢或內容 極其本產品訪問位址。
- B.被移除內容的合法性證明，包括但不限於您對已移除的內容擁有著作權或其他合法權益的權屬證明或您可以合法使用該作品或該內容的證明。
- C.請提供具體的聯絡諮詢，包括姓名、身份證或護照影本（對自然人）、單位登記證影本（對單位）、通信地址、電話號碼、傳真和電子郵件。
- D.請在反通知中加入如下關於反通知內容真實性的聲明
a.我本人為該作品/該內容的合法權利人。
b.我有權或已獲授權提供或刊登上述被移除的諮詢或內容。
c.本人確認：如果本反通知內容不完全屬實，本人將承擔由此產生的壹切法律責任。
- 5.請在反通知中加入以下陳述：我保證，本反通知中所述資訊是充分、真實、準確的，我是該作品/該內容的合法權利人，或我已獲授權或依法可以使用第2項中列明作品/內容。

6.請您簽署該檔，如果您是依法成立的機構或組織，請您加蓋公章。

請您把以上資料和聯系方式回饋至：launcheros888@gmail.com

Product packaging content

Numbering	Part Name	Quantity
1	EVPAD	1
2	Remote Control	1
3	USER Manual	1
4	HD Cable	Optional
5	AC Adapter	1

*The HD cable is optional,please ask the agent if you have any problem.
*Specifications and appearances of any product are only for information, take practicality as standard.
*It is recommended that users choose HD Cable with a length of not more than 1.2 meters, 128 braid nets and four layers of shielded dual magnetic rings.


Product service

Warranty Period
1. The purchase of the company's products can enjoy one year from the date of purchase of the warranty period. Special agreement to extend the sale period.
2. During the warranty period, users can enjoy valid purchase certificate free of charge after-sales maintenance services.

The following is not a free warranty EVPAD can provide paid service
1. Has exceeded the valid warranty period.
2. Failure to follow the instructions required by the installation, use, maintenance and storage of the fault or damage.
3. Failure or damage caused by repair by a NON-EVPAD authorized service person.
4. Due to accidental factors or that the behavior of the product damage, such as broken, Water, input voltage, corrosion, etc.
5. Unauthorized changes to the products native configuration files or unverified product firmware without EVPAD'S approval.
6. Unauthorized alteration, tear up the after-sales service card product serial number.
7. Damage caused by transportation, loading and unloading on the way back to repair by customer.
8. Failure and damage caused by flood, fire, lightning and other irresistible.
9. Other non-product itself design, technology, manufacturing quality problems caused by failure or damage

Special Reminder
1. Before use, please be sure to carefully read the product manual
2. Dealers to you to make non-division We commitment to guarantee, We do not assume responsibility for this Division
3. Before product repair, please contact our technical service, seek technical support to confirm the product failure

Installation Diagram



How To Connect To The Internet

- 1.Be sure the network cable which connected to set-top box is from router,and the router DHCP feature is turn on.
- 2.Connect the network cable into Lan port of set top box ,make sure it is good contact for internet cable and router.



Connect WIFI

Set >Wifi>Select the desired wireless connection > Enter password



服務保障卡/Service Warranty

尊敬的用戶您好，此卡片將用於設備保修及服務認定的唯一憑證，請妥善保存。
Dear users,this card is the only certificate for device maintenance and service affirmation so please keep it properly

產品型號/Product type _____

機身MAC碼/MAC Code _____

經銷商名稱/Name of dealer _____

經銷商聯擊方式/Contact of dealer _____

銷售日期/Sale date _____

銷售授權碼/Authorization Code _____

購買價格/Purchase price _____

維修記錄/Maintenance record

日期 Date	故障現象 Phenomenon of fault	故障原因 Reason of fault	處理方式 Treatment



產品說明書
PRODUCT MANUAL

使用前請仔細閱讀本手冊，並妥善保管
Please read this manual before use and keep it in a safe place.

本說明書適用於EVPAD & EVAI 系列產品
This manual is for EVPAD & EVAI products

本產品僅限於中國大陸以外地區銷售
This product is for sale out of mainland China